

RTDs and Metal Transitions Style



- **1.** PSR-222 Style
- Sheath 316
- **2.** Calibration
- Pt100Ω 3Wire
- **3.** Number Of Element
- S = Single
- D= Double
- **4.** Sheath O.D.(mm)
- 3 = 3.2(mm)
- 4 = 4.8 (mm)
- 6 = 6.4 (mm)
- 8 = 8.0 (mm)
- **5.** Junction
- U = Ungrounded
- **6.** Sheath Length (L)
- A = 100
- B = 150
- C = 200
- D = 50 - 999
- **7.** Lead Length(L)
- A = 1000(mm)
- B = 2000(mm)
- C = 3000(mm)
- D = 4000(mm)
- E = 5000(mm)